

# iQ-rig



## Quick Setup Guide

Some Assembly Required (See picture on box)

The iQ-rig ships WITHOUT the batteries installed in the mic. INSERT batteries as follows:

1. Remove the iQ-rig from the box.
2. Unscrew the mic cable from the mic base by twisting the mic off the cable.
3. Carefully remove the mic from the shockmount and take care not to misplace the windscreen.
4. Hold the mic with the shotgun pointing up, and grip the barrel just above the Q with one hand, and the base just below the Q with the other hand.
5. Gently twist off the bottom base of the mic and place the shotgun barrel on a safe surface. (Do not drop!)
6. Insert the two batteries with the face up (writing showing) into the base of the mic.
7. Gently screw the mic base back onto the shotgun barrel, being careful to avoid cross threading.
8. Twist the mic back onto the mic cable, and insert back into the shockmount.
9. Insert your phone into the clamp by using your thumb on the back tab to push down firmly. (See picture)
10. Position the phone as desired with the lens on top and opposite the mic.  
This will vary depending on the phone you are using. Tighten as necessary.
11. Plug the QCBL7 into the phone's TRRS compatible jack.
12. Connect your headphones / ear buds to the female jack on the opposite end of the QCBL7 square connector plug.
13. Turn the mic to the ON position when ready, and turn OFF mic when finished to preserve battery life.



**NOTE: Some phones may need to be turned off and then back on, with the QMSG1 plugged in and turned ON, to register and “activate” the MSG1 as an external mic plugged in to your phone. Always check to makes sure that the MSG1 is recording, and not the internal mic, when you first start recording or when turning the mic back on. Check out the iQ-rig web page at [www.queaudio.com](http://www.queaudio.com) for in-depth instructional videos and tips!**

## iQ-rig lite

### Quick Setup Guide

Comes Fully Assembled (See picture on box)

1. Insert the phone into the clamp and position as desired with the lens on top and opposite the mic. (See picture above)
2. Insert QCBL7 3.5mm female barrel in handle and plug other end into phone.
3. Attach the mic of choice and plug into the 3.5mm female barrel.
4. Connect headphones or ear buds if desired to the 3.5mm female headphone jack located on the square connector, which is now attached to the phone.
5. Check out the iQ-rig web page at [www.queaudio.com](http://www.queaudio.com) for in-depth instructional videos and tips!

## iQ-rig junior

### Quick Setup Guide

Comes Fully Assembled (See picture on box)

1. Insert the phone into the clamp and position as desired with the lens on top and opposite the mic. (See picture above)
2. Check out the iQ-rig web page at [www.queaudio.com](http://www.queaudio.com) for in-depth instructional videos and tips!